



NOTES:
 1. USE #2 TYPE B THREAD FORMING SCREWS TO INSTALL THE CIRCUIT CARD ASSEMBLY.

PACINTEC[®]
 1-610-361-4231

XPM-9VB/2AA

VISIT **PACINTEC**[®]
 ON THE WORLD WIDE WEB
www.pactecenclosures.com

COLOR / MATERIAL CODE		
COLOR	94HB	94VO
BLACK	000	028
P. C. BONE	039	060